

Effect of Diver Thermal Status on Nitrogen Uptake and Elimination

Pendergast, D.R., Senf, C., Lundgren, C.E.G.

Center for Research and Education in Special Environments, (CRESE)

Department of Physiology and Biophysics

School of Medicine and Biomedical Sciences University at Buffalo

Buffalo, NY 14214



dpenderg@buffalo.edu (716-829-3830)

clundgre@buffalo.edu (716-829-2310)






Aim: Enhance N2 Elimination





- Breathing oxygen (or oxygen-enriched gas mixtures)
- Boosting blood perfusion by physiological mechanism acting via increased cardiac output and tissue blood flow
- Circulation effects both uptake and elimination
 - Immersion in water
 - Supine or Head-down tilt positions
 - Negative pressure breathing during recumbence
 - Exercise: during decompression does, but pre-dive does not
 - Thermal environment

Method: N₂ Washout



- Closed circuit
- Bag-in-Box
- O₂ (21%)/Argon:
O₂ add system
- CO₂ scrubber
- Subject in tent: Argon to
prevent N₂ uptake through
skin
- N₂ by Gas Chromatograph
- Vol: wet spirometer
- Collection at 5" and 10"
intervals
- First collection is corrected
for lung N₂



Calculations: total N₂ elimination and half time calculated from extrapolated total N₂

Inclusion criteria: Exponential rise to asymptote by extrapolation required to agree with total predicted N₂ store based on body mass and composition and solubility coefficients

Method highly reliable based on test-retest data (slope = 0.98)

The present data agree with our previously published data and calculations from estimates of body mass and composition



A novel methodological approach to evaluate fractionated N₂ uptake and elimination



Measurements of whole-body uptake of N₂ have, to our knowledge, not been performed earlier. This is because of the great error inherent in measuring the disappearance (uptake) of a few ml of N₂ per minute from a ventilatory minute volume containing some 6,000-8,000 ml of N₂. The present method circumvents this problem employing the following methodological steps in this study of temperature effects on N₂ exchange:



A novel methodological approach to evaluate fractionated N₂ uptake and elimination



1. Preparatory washout phase: the tissue N₂ is washed out during 2 hrs of oxygen or, in this study, a 21% O₂/Ar mixture in thermo-neutral ambient temperature.
2. Loading phase (“field condition”: bottom sojourn): directly following (1) fresh air is breathed for 2 hrs in either a thermo-neutral, cool or warm environment.
3. Washout phase (“field condition”: decompression or preparation for decompression): Immediately following (2) the tissue N₂ is washed out during 2 hrs of breathing oxygen or, in this study, a 21% O₂/Ar mixture in a thermo-neutral, cool or warm environment.



Effect of thermal environment



- Divers are exposed to cold and warm water which effects both N_2 uptake and elimination
- CO increases in warm environment and decreases in cold, reflecting changes in peripheral vascular resistance
- Skin and muscle blood flows decrease in cold water and skin blood flow increases in warm water
- Vasoconstriction should decrease N_2 uptake
- Vasodilatation should increase N_2 washout
- Thus, cooling during compression and warming during decompression should reduce uptake and facilitate washout
- Hypothesis is supported by:
 - a. Theoretical analysis (Olszowka/Pendergast, 1989)
 - b. NEDU study showing less DCS and VGB after a cold-warm dive than cold-cold (Gerth/Rutherfordbusch/Long, 2007)



Thermal status and N₂ Washout



- Subjects: n = 8 males
- N₂ Washout measured as described above

- Protocol:




	Washout	Wash in	Washout
Gas:	O2/argon	Air	O2/argon
Time:	2hrs	2hrs	2hrs
Temp.	TN	TN	TN
	TN	Cold	Cold
	TN	Cold	Warm
	TN	Warm	Cold
	TN	Warm	Warm

- Measurements: BP & CO (Finnometer), O2 sat (Nonin), Tskin (thermistor), Tcore (CoreTemp)



- 6 Heater/chiller units (Julabo) or DTPS with variable set-points perfusing the tube suit
- tube suit with 6 individually perfused zones (head, torso, arms, hands, legs, feet)
- Insulation: thin dive shell

Repeated N₂ washouts in thermally neutral conditions







Thermal Conditions



Skin Temperature




Core Temperature






Physiological Responses



Total N₂ washed in




- 23% less N₂ washed in during cold than when thermally neutral
- 8% more washed in during warm than when thermally neutral




Temperature effect on N₂ elimination



Avg. 2nd washout data (n=8)



N₂ wash out slower in CC and faster in H-H



The data from this project demonstrated that:

- Thermal environment effects N₂ uptake/washout:
As expected, uptake is less in cool environment and washout is faster in warm, confirming previous theory and NEDU experiments demonstrating less VGB and DCS under similar conditions
- Technology (DTPS) currently exists to keep divers cool at the bottom and warm during in-water decompression

