

Milestones of the deep diving research laboratory Zurich

Bühlmann Symposion 29./30. März 2019

Universitätsspital Zürich (DKL-USZ)

Jürg Wendling, Peter Nussberger, Benno Schenk
mail@wendling.ch

Deep-Diving Research Laboratory Zürich

Hannes Keller (Project Director -64)
Prof.A.A.Bühlmann (Medical Director, †94)
Benno Schenk (Technical Director, 64-)

-
-
- 1959–1963 Proving the feasibility of deep-diving with Heliox
- 1964-1981 Development of deco-tables for offshore work
- 1972-1986 Altitude dive-tables for SCUBA bounce-diving
- 1983-1994 Support for development of dive computers
- Conclusions

Hannes Keller

Scuba Diver

Mathematics High-School Teacher

Friend of IBM Manager and Programmer

Knowledge of USN Heliox Tables

Hypothesis: Diving deeper than 180 m possible with

- avoiding narcosis by replacing N_2 by He
- pre-oxygenation (max. N_2 elimination)
- reducing inert gas load by ultra-fast descent
- fast decompression by using counter-diffusion effect, multiple gas switches

Prof. A.A. Bühlmann

- Medical Doctor, Internal Medicine Specialist, University Zürich
- Research in lung physiology
- Interested in Haldane and Dwyer approach for gas exchange simulation

Hypothesis:

Diving with air would work even for deeper dives, if sufficient CO₂ elimination was assured (Narcosis = CO₂ retention phenomenon)

Early Deep-diving experiments

1915	91 m	air (free dive)	USN [N ₂ narcosis]
1919	?	heliox (experiments)	Thompson
1937	127 m	heliox (free dive)	Nohl/End
1937	150 m	heliox (simulation)	Nohl/End
1939	73 m	heliox (squalus lifting)	USN [He Tables, closed circ.]
1945	159 m	H ₂ -O ₂ (free)	Zetterströhm [blow-up, †]
1956	180 m	heliox (free)	RN [surface supplied]
1958	<i>Start of H. Keller/A. Bühlmann-experiments</i>		

Proving the feasibility of deep-diving to 300m 1959-63

- 1959 Fresh water record 122m Lake of Zurich
- 1960 Fresh water record 222m Locarno
- 1961 60min work 90m research cham.
- 1961 10min work 220m sim. (4bar)
- 1961 10min work 220m cham. (Toulon)
- 1961 10min work 220m cham. (USN)
- 1962 World record (sea) 300m California




video



FIG. 2. Nine subjects, 300-ft dive with 60 min bottom time.

Vorausberechnung und Testung des Versuchs in einer 1-Mannkammer mit 5 verschiedenen Atemgasgemischen






Abb. 2. Vorherige Testung des Dekompressionsprofils der Tauchgänge am 26.04. 1961 und 10.05. 1961 mit der Kombination von Überdruck und Unterdruck. Von 1,0 bar bis 0,5 bar wurde 50% O₂ + 50% N₂ und von 0,5 bis 0,2 bar 100% O₂ eingeatmet. Der Aufenthalt bei 0,2 bar dauerte 30 min, was für das Auftreten von Schmerzen als Zeichen einer ungenügenden Dekompression zu kurz ist





Abb. 1. Exposition während 10 min bei 22,0 bar. Kontinuierliche Kompression und Dekompression mit 5 verschiedenen Atemgasen. Bei 22,0 bar leichte Arbeit mit Gewichtheben im Wasser. Dekompressionszeit 140 min












FIG. 6. Two subjects, 1,000-ft dive with 5 min bottom time.



Development of decompression tables for offshore work 1964-1981

- 3 compartment sat system at ZHL designed for 4bar (30m) in 1964
- 2 chamber sat system with wet bell at ZHL designed for 100bar, Helium mixes, in-water working) in 1972
- Verification dives with SSOS and Micoperi
- Mixgas tables for bounce and sat deco to 300m



Experimental long Air Dives at 4 ATA (30 m), Decompression with O₂

Bottom Time (h)	Effect. Decotime (min)	Calculated Deco-time for O ₂ (min)	% O ₂	OK	DCI	Skin	Muscles	Shoulder	Hip	Knee	Foot
3h	58'	58'	100	○	●		●				
4h	73'	73'	100	○	●		●				
4h	62'	62'	100	○○							
5h	70'	70'	100	○○○	●				●	●	
6h	70'	70'	100		●●		●	●			●
6h	80'	80'	100	○○○	●●		●			●	
6h	90'	90'	100	○	●				●		
7h	80'	80'	100		●●	●	●	●			
7h	90'	90'	100	○○	●●	●	●	●	●		
7h	100'	100'	100	○○○	●●●	●	●	●	●	●●	
8h	120'	120'	100	○	●					●	
8h	130'	130'	100		●●					●●	
8h	585'	200'	20	○○							
9h	140'	140'	100	○	●			●			
9h	150'	150'	100	○	●					●	
10h	150'	150'	100		●●		●		●	●●	
11h	170'	170'	100		●●				●	●●	
11h	335'	270'	80	○○							
12h	200'	200'	100	○	●					●	
14h	230'	230'	100		●●				●	●●	
14h	250'	250'	100	○	●		●			●	
14h	270'	270'	100	○	●				●	●	
14h	330'	330'	100	○○							
16h	330'	330'	100	○○							
20h	350'	350'	100	○	●					●	
20h	500'	375'	70	○○							
24h	510'	380'	70	○○							
28h	460'	350'	70		●●					●●	
42h	560'	430'	70		●●		●		●	●	●
42h	600'	450'	70	○○							
44h	615'	450'	70	○○							
48h	600'	450'	70	○	●		●				
Total				43	37						

A Bühlmann P.Frei H.Keller 1967 Saturation and Desaturation with N₂ and He at 4atm

DECOMPRESSION-
TIME IN MINUTES

4 ATM. 79% N₂

500

400

300

200

100

480'

420'

360'

240'

120'


••O.K.
••BENDS

BOTTOM TIME IN HOURS

4 8 12 16 20 24 28 42 46 50


Milestones deep

20



Development of Decompression Tables for offshore Work (1964 – 1981)


- Capshell series
- Alverstoke series
- Atlantis series
- DKL 72 series
















AUFBAU UND FUNKTIONS-PRINZIP DES DRUCKKAMMERSYSTEMS KSZ







Bounce dives to 40–250m

DECOMPRESSION TABLE

Code No. 220. HHAMO. 70. A1

BREATHING MIXTURE

5 % O₂ / 95 % He

BREATHING MIXTURES FOR DECOMPRESSION

10 % O₂ / 90 % He

Air

50 % O₂ / 50 % N₂

100 % O₂

COMPRESSION TIME 22 min.

220	BOTTOM TIME (excluding compression time)													
	15	30	45	60	75	90	105	120	135	150	165	180		
	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min
to 1. STOP	5	5	5	5	5	5	5	5	5	5	5	5	5	5
STOP 1	163	169	170	170	170	170	170	170	170	170	170	170	170	170
2	142	147	150	155	158	159	161	161	161	161	161	161	161	161
3	110	130	140	147	150	151	152	153	153	153	153	153	153	153
4	98	117	125	131	134	138	141	144	142	143	143	143	143	143
5	86	104	111	119	124	130	133	135	135	136	138	138	138	138
6	72	92	100	111	114	118	125	127	127	129	131	131	131	131
7	65	83	91	104	101	113	117	123	123	125	124	124	124	124
8	57	71	85	91	101	105	116	116	116	115	115	115	115	115
9	49	63	75	80	84	93	101	110	110	109	107	107	107	107
10	37	57	68	74	79	87	92	101	106	106	106	106	106	106
11	29	52	65	70	70	81	86	92	95	95	95	95	95	95
12	19	49	59	63	66	75	80	85	88	88	88	88	88	88
13	11	41	54	57	61	68	76	81	83	83	83	83	83	83
14	11	35	48	53	56	61	68	75	79	79	79	79	79	79
15	5	28	39	43	46	51	56	61	64	64	64	64	64	64
16	5	22	32	36	39	43	48	53	56	56	56	56	56	56
17	5	18	27	30	33	37	41	46	50	50	50	50	50	50
18	5	15	23	26	29	33	37	41	45	45	45	45	45	45
19	0	12	20	23	26	30	34	38	42	42	42	42	42	42
20		11	19	22	25	29	33	37	41	41	41	41	41	41
21		7	14	17	20	24	28	32	36	36	36	36	36	36
22		5	11	14	17	21	25	29	33	33	33	33	33	33
23		5	9	12	15	19	23	27	31	31	31	31	31	31
24		5	8	11	14	18	22	26	30	30	30	30	30	30
25		0	8	10	13	17	21	25	29	29	29	29	29	29
Total Decomp. Time	700	915	turn over	turn over	turn over	turn over	turn over	turn over	turn over	turn over	turn over	turn over	turn over	turn over


Code No. 220. HHAMO. 70. A2

220	15	30	45	60	75	90	105	120	135	150	165	180		
	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min
	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min	m min
STOP 26			0	5	8	13	18	25	30	43	55	69	84	100
27				3	6	9	13	18	24	35	49	63	78	94
28				2	5	8	12	17	23	34	48	62	77	93
29				2	4	7	11	16	22	33	47	61	76	92
30				0	3	6	10	15	21	32	46	60	75	91
31					0	5	9	14	20	31	45	59	74	90
32						3	7	12	18	29	43	57	72	88
33						2	6	11	17	28	42	56	71	87
34						0	5	10	16	27	41	55	70	86
35							3	8	13	24	38	52	67	83
36							2	7	12	23	37	51	66	82
37							0	6	11	22	36	50	65	81
38								0	5	11	21	35	50	65
39									0	4	10	20	30	40
40										0	3	9	19	29
41											0	2	8	18
42												0	1	7
43													0	6
44														5
45														4
46														3
47														2
48														1
49														0
50														
51														
52														
53														
54														
55														
56														
57														
58														
59														
60														
Total Decomp. Time			1115	1336	1520	1655	1790	1915	2055	2175	2255	2325		

SION TABLE


HHAMO. 70. A1

BREATHING MIXTURE

 5 % O₂ / 95 % He

COMPRESSION TIME 22 min.

BREATHING MIXTURES FOR DECO

 10 % O₂ / 90 % He

 Air

 50 % O₂ / 50 % N₂

 100 % O₂

BOTTOM TIME (excluding compression time)

15		30		45		60		75		90		105		120		135		150		165	
m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min
	5		5		5		5		5		5		5		5		5		5		5
163	5	169	5	170	5	170	5	170	5	170	5	170	5	170	5	170	5	170	5	170	5
142	10	147	5	150	5	155	5	158	5	159	5	161	5	161	5	161	10	161	10	162	10
110	10	130	10	140	10	147	10	150	10	151	10	152	10	153	10	151	10	153	10	154	10
98	10	117	10	125	10	131	10	134	10	138	10	141	10	144	10	142	15	143	15	150	10
86	15	104	10	111	15	119	10	124	15	130	15	133	15	135	10	136	15	138	15	144	10
72	15	92	15	100	15	111	15	114	30	118	15	125	30	127	10	129	15	131	15	138	15

75	90		105		120		135		150		165		180	
min	m	min	m	min	m	min	m	min	m	min	m	min	m	min
60	13	120	25	120	30	90	43	90	49	60	55	60	59	60
60	9	60	18	120	24	120	35	90	42	90	53	60	57	60
60	7	60	13	120	18	120	28	120	35	90	51	60	55	60
60	5	60	9	60	13	120	22	120	29	120	49	60	53	60
	3	60	7	60	9	60	16	120	22	120	44	90	51	60
	2	60	5	60	7	60	12	120	15	120	35	90	49	60
	0		3	60	5	60	9	60	11	120	28	120	44	90
			2	60	3	60	7	60	9	60	21	120	35	90
			0		2	60	5	60	7	60	16	120	28	120
					0		3	60	5	60	11	120	21	120
							2	60	3	60	9	60	16	120
							0		2	60	7	60	11	120
									0		5	60	9	60
											3	60	7	60
											2	60	5	60
											0		3	60
													2	60
													n	
1520	1655		1790		1915		2055		2175		2255		2325	
25.3h	27.6h		29.8h		31.9h		34.3h		36.3h		37.6h		38.7h	

Saturation deco-tables

DECOMPRESSION TABLE FOR SATURATION DIVES

Code No. 15 – 60 SAT. A. 70. A1

BREATHING MIXTURE						
DIVING DEPTH m	15		20		25	
	m	min	m	min	m	min
to 1. STOP	10		10		10	
STOP 1	5	110	8	110	11	110
2	4	180	7	180	10	180
3	3	180	5	180	9	180
4	2	180	4	180	7	180
5	0		3	180	5	180
6			2	180	4	180
7			0		3	180
8					2	180
9					0	
10						
11						
12						
13						
14						
15						
16						

BREATHING MIXTURES FOR DECOMPRESSION

- 5% O₂ / 95% He
- 10% O₂ / 90% He
- Air
- 100% O₂

DEEP DIVING RESEARCH LABORATORY
DEPARTMENT OF INTERNAL MEDICINE
UNIVERSITY HOSPITAL ZÜRICH

DECOMPRESSION TABLE FOR SATURATION DIVES

Code No. 15 – 60 SAT. A0. 70. A1

BREATHING MIXTURE		15		20		25	
DIVING DEPTH m							
		m	min	m	min	m	min
to 1. STOP		10		10		10	
STOP 1		5	110	8	110	11	110
2		4	120	7	180	10	180
3		2	120	5	120	9	180
4		0		4	120	7	180
5				2	120	5	120
6				0		4	120
7						2	120
8						0	
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							
1 Decompr. Time				6h		11h	

BREATHING MIXTURE
Air

BREATHING MIXTURES FOR DECOMPRESSION

100% O₂

DEEP DIVING RESEARCH LABORATORY
DEPARTMENT OF INTERNAL MEDICINE
UNIVERSITY HOSPITAL ZÜRICH


DECOMPRESSION TABLE FOR SATURATION DIVES

Code No. 20 – 130 SAT. HHA. 70. A1

BREATHING MIXTURE	10% O ₂ / 90% He												5% O ₂ / 95% He					
DIVING DEPTH m	20		30		40		50		60		70		80		90		100	
	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min
to 1. STOP	5		5		5		5		5		10		10		10		10	
STOP 1	11	55	19	55	27	55	35	55	43	55	50	50	63	80	71	80	80	80
2	9	60	16	60	25	60	31	90	41	120	48	90	60	90	68	90	75	90
3	7	60	14	90	21	60	25	90	38	120	45	90	57	90	64	90	72	90
4	5	60	11	90	18	90	20	90	28	120	42	120	53	90	60	90	68	90
5	3	90	8	90	14	90	17	90	22	120	38	120	50	120	57	120	64	90
6	2	90	5	120	10	120	14	90	18	120	28	120	48	120	53	120	60	90
7	0		3	120	7	120	12	120	13	120	22	120	42	120	50	120	57	120
8			2	90	5	120	9	120	9	120	18	120	38	120	48	120	53	120
9			0		3	120	7	120	7	120	13	120	28	120	42	120	50	120
10					2	120	5	120	5	120	9	120	22	120	38	120	48	120
11					0		3	120	3	120	7	120	18	120	28	120	42	120
12							2	90	2	120	5	120	13	120	22	120	38	120
13							0		0		3	120	7	120	13	120	22	120
14											2	120	5	120	9	120	18	120
15											0		3	120	7	120	13	120
16													2	120	5	120	9	120
17													0		3	120	7	120
18															2	120	5	120
19															0		3	120
20																	2	120
21																	0	
22																		
23																		
24																		
25																		
Total Decompr. Time	7 ^h		12 ^h		16 ^h		20 ^h		23 ^h		26 ^h		32 ^h		36 ^h			

BREATHING MIXTURE		10 % O ₂ / 90 % He										5 % O ₂ /							
DIVING DEPTH m		20		30		40		50		60		70		80		90		100	
	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min	m	min	
to 1. STOP		5		5		5		5		5		10		10		10		10	
STOP 1	11	55	19	55	27	55	35	55	43	55	50	50	63	80	71	80	80	80	
2	9	60	16	60	25	60	31	90	41	120	48	90	60	90	68	90	75	90	
3	7	60	14	90	21	60	25	90	38	120	45	90	57	90	64	90	72	90	
4	5	60	11	90	18	90	20	90	28	120	42	120	53	90	60	90	68	90	
5	3	90	8	90	14	90	17	90	22	120	38	120	50	120	57	120	64	90	
6	2	90	5	120	10	120	14	90	18	120	28	120	46	120	53	120	60	90	
7	0		3	120	7	120	12	120	13	120	22	120	42	120	50	120	57	120	
8			2	90	5	120	9	120	9	120	18	120	38	120	46	120	53	120	
9			0		3	120	7	120	7	120	13	120	28	120	42	120	50	120	
10					2	120	5	120	5	120	9	120	22	120	38	120	46	120	
11					0		3	120	3	120	7	120	18	120	28	120	42	120	
12							2	90	2	120	5	120	13	120	22	120	38	120	
13							0		0		3	120	9	120	18	120	28	120	
14											2	120	7	120	13	120	22	120	
15											0		5	120	9	120	18	120	
16													3	120	7	120	13	120	
17													2	120	5	120	9	120	
18													0		3	120	7	120	
19															2	120	5	120	
20															0		3	120	
21																	2	120	
22																	0	120	
23																			
24																			
25																			
Total Decompr. Time		7 ^h		12 ^h		16 ^h		20 ^h		23 ^h		26 ^h		32 ^h		36 ^h			


BREATHING MIXTURES FOR DECOMPRESSION



5 % O₂ / 95 % He



10 % O₂ / 90 % He



Air



100 % O₂

2 % O ₂ / 98 % He												
	200		210		220		230		240		250	
	m	min	m	min	m	min	m	min	m	min	m	min
0		20		20		20		20		20		20
0	174	70	183	70	194	70	202	70	212	70	222	70
0	170	90	179	90	188	90	197	90	206	90	217	90
0	165	90	174	90	183	90	190	90	200	90	210	90
0	161	90	170	90	179	90	185	90	195	90	206	90
0	156	90	165	90	174	90	179	90	190	90	200	90
0	152	90	161	90	170	90	174	90	184	90	195	90
0	146	90	156	90	165	90	170	90	179	90	190	90
0	140	90	152	90	161	90	165	90	174	90	184	90
0	135	90	146	90	156	90	161	90	170	90	179	90
0	130	90	140	90	152	90	156	90	165	90	174	90
0	124	90	135	90	146	90	152	90	161	90	170	90
0	120	90	130	90	140	90	146	90	156	90	165	90
0	114	90	124	90	135	90	140	90	152	90	161	90
0	110	90	120	90	130	90	135	90	146	90	156	90
0	106	90	114	90	124	90	130	90	140	90	152	90
0	102	90	110	90	120	90	124	90	135	90	146	90

Problem: HPNS

high pressure nervous syndrom

- After first experiments HPNS existence denied
- From increasing compression speed to constant speed to depth
- From constant speed to staged compression

HPNS with varying descent techniques

A. Continuous compression, increasing with depth

215 m	in 3'	(20-50 m/'↓)	O ₂ -N ₂ -He	HPNS -	(n=2, 1961)
250 m	in 5',10'	(20-50 m/'↓)	O ₂ -N ₂ -He	HPNS -	(n=3, 1960/62)
300 m	in 16'	(20-50 m/'↓)	O ₂ -N ₂ -He	HPNS (+)	(n=5, 1961/62)

B. Continuous compression, constant


220 m	in 22'	(10 m/'↓)	O ₂ -He	HPNS -	(n=16, 1965-68)
250 m	in 25'	(10 m/'↓)	O ₂ -He	HPNS +	(n=11, 1967-80)
300 m	in 30'	(10 m/'↓)	O ₂ -He	HPNS +	(n=30, 1967-80)
350 m	in 35'	(10 m/'↓)	O ₂ -He	HPNS ++	(n= 6, 1977)
500 m	in 50'	(10 m/'↓)	O ₂ -He	HPNS +++	(n= 3, 1977)

C. Staged compression, continuous compression rate


300 m	in 155'	(10 m/'↓)	O ₂ -He	HPNS (+)	(n=6, 1978)
350 m	in 325'	(4 m/'↓)	O ₂ -He	HPNS -	(n=3, 1969)
400 m	in 255'	(10 m/'↓)	O ₂ -He	HPNS ++	(n=3, 1979)
400 m	in 415'	(10 m/'↓)	O ₂ -He	HPNS -	(n=3, 1981)
500 m	in 700'	(10 m/'↓)	O ₂ -He	HPNS +	(n=3, 1981)

© A. Bühlmann 1993, Tauchmedizin


1977











The global decompression algorithm ZHL 16A

- Model valid for any gas composition
- Model valid for short, medium and long exposures to saturation
- Deterministic model (based on max. tolerated tissue supersaturation)





Abb. 26. N_2 -Halbwertszeit 27,0 min. Die experimentellen Werte für den $p_{t.N_2}$ weichen nur wenig von der „theoretischen“ Linie entsprechend den Koeffizienten von ZH-L16A ab.

$$P_{amb.tol.} = (p_{t.N_2} - 0,6667) \cdot 0,8126$$

(A.A. Bühlmann, Tauchmed. 3. Aufl.)







FIG. 31-1: A TYPICAL DECOMPRESSION DIVE PROFILE WITH CEILING LINE VISIBLE. THE NUMBERS REPRESENT DIFFERENT PHASES (SEE PHASES IN FIG. 31-2)






Abb. 24. Theoretisch tolerierter $p_t \text{He}$ und $p_t \text{N}_2$ bei einem Umgebungsdruck von 1,0 bar entsprechend den Koeffizienten ZH-L16A. Abhängigkeit von den Halbwertszeiten. Längste He-Halbwertszeit 240 min, längste N₂-Halbwertszeit 635 min. • $p_t \text{He}$ - und $p_t \text{N}_2$ -Werte mit Symptomen der Dekompressionskrankheit bei verkürzter Dekompressionszeit auf der letzten Stufe (Tabellen 21 und 22)

Verification studies for air bounce tables

- Aim to get standard for SCUBA diving guidance
- Verification using altitude dives
- Validation experiments with reduced decompression stops
(+ 10% deco-stress → 30% increase of DCS)
DCS treated in the recompression chamber




















DEKOMPRESSIONSTABELLE
Höhenbereich: 500 bis 600 müM.
Luft-Atmung

Koeffiziente
Anfahrtszeit
Anfahrtszeit
Luftdruckto
untere Luft
obere Luft
Druckzuschl
Druckzuschl
max. Gesam
Entsättigu
Entsättigu
Entsättigu
GZ: Grund
tD: Aufst
tA: Gesam
tT: total
RG: Repet
Druckang
Zeitanga

DEKOMPRESSIONSTABELLE
Höhenbereich: 500 bis 600 müM.
Sauerstoff-Atmung für Dekompressionsstufen ≤ 0.9 bar !


Koeffizientensatz: ZHL-16B
Anfahrtszeit: 300 müM.
Anfahrtszeit: 300 min.
Luftdrucktoleranz: +/- 10 mbar
untere Luftdruckgrenze: 933 mbar
obere Luftdruckgrenze: 964 mbar
Druckzuschlag auf Tiefe: 0.02 bar + 1%
Druckzuschlag auf Deko: 0.02 bar + 1%
max. Gesamttauchzeit: 480 min.
Entsättigungszeiten: Repetivgruppe X: 56 h
Entsättigungszeiten: Repetivgruppe Y: 64 h
Entsättigungszeiten: Repetivgruppe Z: 72 h
GZ: Grundzeit
tD: Aufstiegszeit bis zur ersten Dekostufe
tA: Gesamtaufstiegszeit bis Umgebungsdruck
tT: Gesamttauchzeit
RG: Repetivgruppe
Druckang





Support for development of dive computers 1983 - 1994

- First challenge was to use limited hardware for real time calculation of N₂ partial pressures
- Second challenge was to introduce arterial bubbles and pulmonary blood shunting into the algorithm
- Many more adaptations later with increasing hardware resources and scientific input of influencing factors








Abb. 22. Intrapulmonaler Rechts-links-Shunt in Prozent des Herzzeitvolumens nach einem Tauchgang. Infolge Kumulation der Mikrogasblasen in den Lungenkapillaren wird kurzfristig ein Maximum erreicht. Der Shunt nimmt ab, sobald der Abbau der Mikrogasblasen in der Lunge den Nachschub von Mikrogasblasen aus dem Gewebe übertrifft

aus Buthleier 3

Intrapulmonary right-to-left shunt

Size for some single dives







Abb. 14. Schematische Darstellung des Lungen- und Körperkreislaufs mit unterschiedlichen und variablen Durchblutungsanteilen der verschiedenen Organe



Adaptation of Decompression Algorithm

to bubble induced changes in gas exchange of the lung





Clinical hyperbaric oxygen treatment

HBOT




Development of a high-frequency
ventilation breathing system

by benno schenk





UBA CHARACTERISTICS – DEVELOPMENT PROGRESS

... to reduce work of breathing in deep dives



86.12 SK





Conclusions (1)

- The combination of
 - enthusiasm,
 - scientific commitment
 - opportunity of up-to-date IT-resources

at the ZHL led to a series of spectacular records and research exploits.

Conclusions (2)

- In spite of many improved and modern decompressions models and hypothesis, Bühlmann's validated model with all its simplifications is still the basis for
 - recreational diving computers
 - planning of professional mixed gas operations
 - Teck-dives
 - assessment of profiles from dive accidents.

